

Service
Service
Service



191EW9FB/00
191EW9FB/75
191EW9FB/93
191EW9FB/69
191EW9FB/94
191EW9FB/97
191EW9FB/05
191EW9FB/62



Service Manual

| Description | Page | Description | Page |
|---------------------------------------|------|--|------|
| Table of Contents..... | 1 | 6. Schematic Diagram..... | 18 |
| Revision List..... | 2 | 6.1 Main Board..... | 18 |
| Important Safety Notice..... | 3 | 6.2 Power Board..... | 22 |
| 1. Monitor Specifications..... | 4 | 6.3 Key Board..... | 24 |
| 1.1 Technical Specifications..... | 4 | 7. PCB Layout..... | 25 |
| 1.2 Physical Specifications..... | 5 | 7.1 Main Board..... | 25 |
| 2. LCD Monitor Description..... | 6 | 7.2 Power Board..... | 27 |
| 3. Operation instructions..... | 7 | 7.3 Key Board..... | 29 |
| 3.1 General Instructions..... | 7 | 8. Wiring Diagram..... | 30 |
| 3.2 Control buttons..... | 7 | 9. Scalar Board Overview..... | 31 |
| 3.3 Adjusting the Picture..... | 9 | 10. Mechanical Instructions..... | 32 |
| 4. Input/Output Specification..... | 11 | 11. Repair Flow Chart..... | 36 |
| 4.1 Input Signal Connector..... | 11 | 12. ISP Instructions..... | 42 |
| 4.2 Factory Preset Display Modes..... | 11 | 13. DDC Instructions..... | 45 |
| 4.3 Pixel Defect Policy..... | 12 | 14. White Balance, Luminance Adjustment..... | 52 |
| 4.4 Failure Mode of Panel..... | 13 | 15. Monitor Exploded View..... | 54 |
| 5. Block Diagram..... | 14 | 16. Recommended & Spare Parts List..... | 55 |
| 5.1 Software Flow Chart..... | 14 | 17. Different Parts List..... | 57 |
| 5.2 Electrical Block Diagram..... | 16 | 18. General Product Specification..... | 60 |

SAFETY NOTICE

ANY PERSON ATTEMPTING TO SERVICE THIS CHASSIS MUST FAMILIARIZE HIMSELF WITH THE CHASSIS AND BE AWARE OF THE NECESSARY SAFETY PRECAUTIONS TO BE USED WHEN SERVICING ELECTRONIC EQUIPMENT CONTAINING HIGH VOLTAGES.

CAUTION: USE A SEPARATE ISOLATION TRANSFORMER FOR THIS UNIT WHEN SERVICING

REFER TO BACK COVER FOR IMPORTANT SAFETY GUIDELINES

Revision List

[illegible]

Important Safety Notice

Proper service and repair is important to the safe, reliable operation of all Philips Company Equipment. The service procedures recommended by Philips and described in this service manual are effective methods of performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that this manual contains various CAUTIONS and NOTICES which should be carefully read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper service methods may damage the equipment. It is also important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. Philips could not possibly know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. Consequently, Philips has not undertaken any such broad evaluation. Accordingly, a customer who uses a service procedure or tool which is not recommended by Philips must first satisfy himself thoroughly that neither his safety nor the safe operation of the equipment will be jeopardized by the service method selected.

Hereafter throughout this manual, Philips Company will be referred to as Philips.

WARNING

Use of substitute replacement parts, which do not have the same, specified safety characteristics, may create shock, fire, or other hazards.

Under no circumstances should the original design be modified or altered without written permission from Philips. Philips assumes no liability, express or implied, arising out of any unauthorized modification of design.

Customer assumes all liability.

FOR PRODUCTS CONTAINING LASER:

DANGER- There is invisible laser radiation when open. AVOID DIRECT EXPOSURE TO BEAM.

CAUTION-Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION -The use of optical instruments with this product will increase eye hazard.

TO ENSURE THE CONTINUED RELIABILITY OF THIS PRODUCT, USE ONLY ORIGINAL MANUFACTURER'S REPLACEMENT PARTS, WHICH ARE LISTED WITH THEIR PART NUMBERS IN THE PARTS LIST SECTION OF THIS SERVICE MANUAL.

Take care during handling the LCD module with backlight unit

- Must mount the module using mounting holes arranged in four corners.
- Do not press on the panel, edge of the frame strongly or electric shock as this will result in damage to the screen.
- Do not scratch or press on the panel with any sharp objects, such as pencil or pen as this may result in damage to the panel.
- Protect the module from the ESD as it may damage the electronic circuit (C-MOS).
- Make certain that treatment person's body is grounded through wristband.
- Do not leave the module in high temperature and in areas of high humidity for a long time.
- Avoid contact with water as it may a short circuit within the module.
- If the surface of panel becomes dirty, please wipe it off with a soft material. (Cleaning with a dirty or rough cloth may damage the panel.)

1. Monitor Specifications

1.1 Technical Specifications

| | |
|--------------------------|--|
| LCD PANEL | |
| • Type | TFT LCD |
| • Screen size | 18.5" visual |
| • Pixel Pitch | 0.30 x 0.30 mm |
| • LCD Panel type | 1366 x 768 pixels R.G.B. vertical stripe Anti-glare polarizer, hard coated |
| • Effective viewing area | 409.8 x 230.4 mm |
| • Display Colors | 16.7m |
| SCANNING | |
| • Vertical refresh rate | 56 Hz-76 Hz |
| • Horizontal Frequency | 30 kHz - 83 kHz |
| VIDEO | |
| • Video dot rate | 140 MHz |
| • Input impedance | |
| - Video | 75 ohm |
| - Sync | 2.2K ohm |
| • Input signal levels | 0.7 Vpp |
| • Sync input signal | Separate sync Composite sync Sync on green |
| • Sync polarities | Positive and negative |


1.2 Physical Specifications

| | |
|---------------------|--|
| • Tilt | -5° ~ 20° |
| • Power supply | 100 ~ 240 VAC, 50/60 Hz |
| • Power consumption | <35 W* (typ.) |
| • Temperature | 0° C to 40° C (operating) -20° C to 60° C (storage) |
| • Relative humidity | 20% to 80% |
| • System MTBF | 50K hours (CCFL 50K hours) |
| • Cabinet color | 191EW9FB: Black |

2. LCD Monitor Description

The LCD monitor will contain a main board, a power board and a key board which house the flat panel control logic, brightness control logic and DDC.

The power board will provide AC to DC Inverter voltage to drive the backlight of panel and the main board chips each voltage.



3. Operating Instructions

3.1 General Instructions


Press the power button to turn the monitor on or off. The other control buttons are located at the front of the panel of the monitor.





By changing these settings, the picture can be adjusted to your personal preferences.

- The power cord should be connected.
- Connect the video cable from the monitor to the video card.
- Press the power button to turn on the monitor, the power indicator will light up.


3.2 Control Buttons

Front View



- | | | |
|---|---|--|
| 1 |  | To switch monitor's power on and off |
| 2 | MENU / OK | To access OSD menu/Confirm |
| 3 |  | To adjust brightness of the display |
| 4 |  | Auto picture control switching in wide and 4:3 format |
| 5 | AUTO /  | Automatically adjust the horizontal position, vertical position, phase and clock setting. Return to previous OSD level. |

Rear View




1. Kensington anti-theft lock
2. AC power input
3. VGA input

3.3 Adjusting the Picture

Description of the On Screen Display

On-Screen Display is a feature in all Philips LCD monitors. It allows an end user to adjust screen performance of the monitor directly through an on-screen instruction window. The user interface provides user-friendliness and ease-of-use when operating the monitor.



When you press the **MENU/OK** button on the front control of your monitor, the On-Screen Display (OSD) Main Controls window will pop up and you can then start making adjustments to your monitor's various features. Use the **▲ ▼** keys to make your adjustments.


To Lock/Unlock OSD function (User Mode)

The OSD function can be locked by pressing "MENU" button for more than 10 seconds.

Locked OSD function can be released by pressing "MENU" button for more than 10 seconds again.

The OSD Tree

Below is an overall view of the structure of the On-Screen Display. You can use this as a reference when you want to work your way around the different adjustments later on.




4. Input/ Output Specification

4.1 Input Signal Connector

Analog connectors

| Pin No. | Description | Pin No. | Description |
|---------|-----------------------|---------|------------------------|
| 1. | Red video input | 9. | DDC +5V |
| 2. | Green video input/SOG | 10. | Logic Ground |
| 3. | Blue video input | 11. | Ground |
| 4. | Sense (GND) | 12. | Serial data line (SDA) |
| 5. | Cable detect (GND) | 13. | H. Sync/ H+ V. Sync |
| 6. | Red video ground | 14. | V. Sync |
| 7. | Green video ground | 15. | Data clock line (SCL) |
| 8. | Blue video ground | | |

VGA connector layout



4.2 Factory Preset Display Modes

| H. freq (kHz) | Resolution | V. freq (Hz) |
|---------------|------------|--------------|
| 31.47 | 720*400 | 70.09 |
| 31.47 | 640*480 | 59.94 |
| 37.50 | 640*480 | 75.00 |
| 37.88 | 800*600 | 60.32 |
| 46.88 | 800*600 | 75.00 |
| 48.36 | 1024*768 | 60.00 |
| 60.02 | 1024*768 | 75.03 |
| 63.89 | 1280*1024 | 60.02 |
| 79.98 | 1280*1024 | 75.03 |
| 47.71 | 1366*768 | 59.79 |

4.3 Pixel Defect Policy

| MODEL | 191EW9 |
|---|--------------------|
| BRIGHT DOT DEFECTS | |
| 1 lit sub-pixel | 3 |
| 2 adjacent lit sub-pixels | 1 |
| 3 adjacent lit sub-pixels (one white pixel) | 0 |
| Distance between two bright dot defects* | $\geq 25\text{mm}$ |
| Bright dot defects within 20 mm circle | 0 |
| Total bright dot defects of all type | 3 |
| BLACK DOT DEFECTS | |
| 1 dark sub-pixel | 5 |
| 2 adjacent dark sub-pixels | 2 |
| 3 adjacent dark sub-pixels (one white pixel) | 0 |
| Distance between two black dot defects* | $\geq 15\text{mm}$ |
| Black dot defects within 20 mm circle* | 1 |
| Total black dot defects of all type | 5 |
| TOTAL DOT DEFECTS | |
| Total bright or black dot defects of all type | 5 |

4.4 Failure Mode Of Panel


Quick reference for failure mode of LCD panel

this page presents problems that could be made by LCD panel.
It is not necessary to repair circuit board. Simply follow the mechanical
instruction on this manual to eliminate failure by replace LCD panel.


Failure description

Phenomenon


Vertical block defect



Vertical dim lines




Vertical lines defect
(Always bright or dark)




Horizontal block defect



Horizontal dim lines



Horizontal lines defect
(Always bright or dark)



Has bright or dark pixel



Polarizer has bubbles



Polarizer has bubbles



Foreign material inside
polarizer. It shows liner or
dot shape.



Concentric circle formed



Bottom back light of LCD is
brighter than normal



Back light un-uniformity




Backlight has foreign material.
Black or white color, liner or
circular type



5. Block Diagram


5.1 Software Flow Chat




| |
|--|
| 1) MCU initializes. |
| 2) Is the EPROM blank? |
| 3) Program the EPROM by default values. |
| 4) Get the PWM value of brightness from EPROM. |
| 5) Is the power key pressed? |
| 6) Clear all global flags. |
| 7) Are the AUTO and SELECT keys pressed? |
| 8) Enter factory mode. |
| 9) Save the power key status into EPROM. Turn on the LED and set it to green color. Scalar initializes |
| 10) In standby mode? |
| 11) Update the lifetime of back light. |
| 12) Check the analog port, are there any signals coming? |
| 13) Does the scalar send out an interrupt request? |
| 14) Wake up the scalar. |
| 15) Are there any signals coming from analog port? |
| 16) Display "No connection Check Signal Cable" message. And go into standby mode after the message disappears. |
| 17) Program the scalar to be able to show the coming mode. |
| 18) Process the OSD display. |
| 19) Read the keyboard. Is the power key pressed? |

5.2 Electrical Block Diagram

5.2.1 Main Board




5.2.2 Inverter/Power Board




6. Schematic

6.1 Main Board


715G3213-1




SCALAR









CN401 and CN402 layout together



OUTPUT




POWER




| | |
|-------|----|
| CN404 | A1 |
| C422 | B4 |
| C425 | D1 |
| C426 | B3 |
| C427 | B4 |
| C428 | B3 |
| D401 | A2 |
| D403 | A2 |
| Q406 | D1 |
| R424 | C2 |
| R425 | C3 |
| R426 | B2 |
| R437 | C1 |
| R438 | C3 |
| R440 | D1 |
| R441 | B2 |
| R442 | C1 |
| R443 | C2 |
| R444 | B3 |
| R448 | B2 |
| R457 | B1 |
| U404 | B4 |
| U406 | A4 |


6.2 Power Board


715G2852-2






715G3016-1






7.2 Power Board

715G2852-2




| | | | | | | | |
|-------|----|-------|----|-------|----|--------|----|
| BD901 | D4 | CN601 | D5 | IC903 | C3 | J906 | B4 |
| C604 | C5 | CN602 | B5 | J601 | C5 | J907 | B3 |
| C801 | B1 | CN801 | A1 | J602 | C5 | J908 | A3 |
| C802 | B2 | CN802 | D1 | J605 | B5 | J909 | C4 |
| C803 | C1 | CN803 | A1 | J801 | C2 | J910 | A2 |
| C900 | B4 | CN804 | D1 | J802 | C2 | J911 | A3 |
| C901 | D4 | CN901 | D2 | J803 | B2 | J912 | D4 |
| C902 | D4 | CN902 | A5 | J804 | B2 | J914 | A5 |
| C903 | B3 | D900 | C4 | J805 | B2 | L901 | D3 |
| C904 | D4 | D901 | C3 | J806 | B2 | L903 | A4 |
| C906 | C4 | D905 | A4 | J807 | B1 | L904 | A3 |
| C907 | C4 | D906 | B3 | J809 | A2 | L905 | B5 |
| C908 | D3 | D907 | A4 | J810 | B2 | NR901 | D3 |
| C915 | A4 | F901 | C2 | J811 | A2 | Q901 | C4 |
| C917 | B3 | F902 | B5 | J812 | A2 | R908 | B4 |
| C918 | A3 | F903 | A4 | J813 | A2 | R914 | C4 |
| C921 | B5 | FB602 | B5 | J901 | A3 | R946 | B3 |
| C922 | A3 | FB901 | C4 | J902 | C4 | R948 | A5 |
| C938 | C4 | GND1 | D1 | J903 | C4 | T801 | C2 |
| C939 | A5 | IC601 | C5 | J904 | C4 | T901 | B4 |
| C940 | A4 | IC902 | B3 | J905 | C3 | VAR901 | C2 |




| | | | | | | | | | | | |
|------|----|------|----|-------|----|------|----|------|----|-------|----|
| C601 | D5 | C910 | A4 | IC801 | A2 | R802 | A2 | R841 | A2 | R922 | B4 |
| C602 | B5 | C911 | C3 | IC901 | C3 | R803 | A2 | R850 | B2 | R923 | B5 |
| C603 | C5 | C912 | B3 | JR801 | A2 | R804 | B2 | R851 | A2 | R924 | B3 |
| C606 | D5 | C924 | B3 | JR901 | C3 | R805 | B2 | R853 | A2 | R925 | B3 |
| C608 | C5 | C925 | B3 | JR902 | C3 | R806 | B2 | R854 | B2 | R926 | B3 |
| C609 | B5 | C928 | C3 | Q801 | B2 | R807 | B2 | R855 | B2 | R927 | B3 |
| C610 | D5 | C929 | A4 | Q802 | C2 | R808 | A2 | R856 | C2 | R930 | B3 |
| C611 | D5 | C930 | A3 | Q803 | B2 | R810 | B2 | R861 | B2 | R932 | C4 |
| C612 | C5 | C931 | A5 | Q804 | B2 | R814 | A1 | R862 | A2 | R933 | C3 |
| C613 | C5 | C932 | B3 | Q805 | A1 | R817 | A1 | R863 | A2 | R935 | B4 |
| C807 | A2 | D801 | A1 | Q806 | A2 | R818 | B2 | R864 | B2 | R938 | B4 |
| C817 | B2 | D802 | A2 | Q807 | B2 | R820 | A2 | R865 | B2 | R939 | B3 |
| C819 | A1 | D803 | B1 | Q808 | B1 | R821 | A1 | R900 | D3 | R940 | B3 |
| C820 | B2 | D805 | A1 | Q809 | A2 | R822 | A1 | R901 | C3 | R942 | B3 |
| C821 | A2 | D806 | A2 | Q811 | B2 | R823 | A2 | R902 | D3 | R943 | B3 |
| C822 | A2 | D807 | A1 | Q812 | B2 | R824 | B2 | R904 | C4 | R947 | A5 |
| C823 | A1 | D810 | B2 | Q903 | B3 | R825 | B2 | R905 | C4 | R952 | A5 |
| C824 | B2 | D811 | B2 | Q904 | A5 | R826 | B2 | R906 | C4 | R961 | B4 |
| C825 | B2 | D812 | B2 | R601 | A5 | R827 | A2 | R907 | C3 | R962 | B4 |
| C834 | A2 | D814 | A2 | R602 | B5 | R828 | A1 | R909 | B4 | ZD801 | B1 |
| C835 | A2 | D817 | A2 | R603 | B5 | R829 | B2 | R910 | B4 | ZD902 | B3 |
| C838 | C2 | D903 | B4 | R604 | D5 | R830 | B2 | R912 | C4 | ZD905 | B4 |
| C839 | B2 | D915 | B3 | R605 | D5 | R831 | A2 | R915 | C3 | ZD906 | C3 |
| C842 | A2 | D916 | B3 | R606 | D5 | R832 | A2 | R918 | B3 | ZD921 | B3 |
| C845 | A2 | F801 | A3 | R607 | D5 | R835 | A2 | R919 | B3 | ZD922 | B3 |
| C846 | B2 | F904 | B5 | R608 | D5 | R837 | B2 | R920 | B3 | ZD923 | A5 |
| C909 | C3 | F905 | A4 | R801 | A1 | R839 | B2 | R921 | B4 | | |

7.3 Key Board
715G3016-1




| | | | | | |
|-------|----|--------|----|-------|----|
| CN001 | B5 | LED001 | B3 | SW003 | B1 |
| GND1 | A1 | SW001 | B2 | SW004 | B3 |
| GND2 | A4 | SW002 | B3 | SW005 | B4 |




| | | | | | |
|------|----|------|----|-------|----|
| C001 | A4 | C008 | B3 | R005 | B4 |
| C002 | A3 | C009 | B3 | R007 | A4 |
| C003 | B3 | C010 | B1 | ZD001 | B2 |
| C004 | B4 | R001 | B1 | ZD002 | B4 |
| C005 | A2 | R002 | B2 | ZD003 | B1 |
| C006 | B2 | R003 | B2 | ZD004 | B3 |
| C007 | B4 | R004 | B3 | ZD005 | B3 |

8. Wiring Diagram



9. Scalar Board Overview




10. Mechanical Instructions


1. Place the monitor face down on a smooth surface .Be careful to avoid scratch and injury during the process of uninstal.



2. Remove the three screws remarked in red to remove the Stand-Base ass'y




3. Remove bezel and rear cover




4. Remove main frame cover

A. Disconnect the two connectors marked in blue



B. Remove the two screws marked in red.




C. Remove the two screws marked in red.




5. Remove power board and main board

A. Remove four screws marked in red to remove the Power Board and Main Board from Main Frame.




B. Disconnect the connector marked in blue




11. Repair Flow Chart

11.1 Main Board


(1). No Power



(2). No Picture





(3). White screen




11.2. Power/Inverter Board

(1) No power





11.3 Key Board



12. ISP Instruction

When do the parts, need the tools as follow:

- An i486 (or above) personal computer or compatible.
- Microsoft operation system Windows 95/98/2000/XP.
- “EasyUSB WriterV4.1” program
- Software ISP SN Alignment kits

The kit contents:


- ISP BOARD x1
- Printer cablex1
- VGA cable x1

12.1 Install the “EasyUSB WriterV4.1”





EasyUSB
WriterV4.1.exe


12.2. Connect the ISP board as follow:





12.3. The process of ISP write is as follows.





- a) Double-click  , running the program as follows:





- b) Click  icon and the program runs as follows:



- c) Click  icon, search the program "Philips_191EW9_NT68167_LM190WH1_20080903_V100", and click **open**:



- d) Click  icon. If it burns successfully, it will show as the follow picture:



13. DDC Instruction

General

DDC Data Re-programming

In case the main EEPROM with Software DDC which store all factory settings were replaced because a defect, repaired monitor' the serial numbers have to be re-programmed.

It is advised to re- soldered the main EEPROM with Software DDC from the old board onto the new board if circuit board have been replaced, in this case the DDC data does not need to be re-programmed.

Additional information about DDC (Display Data Channel) may be obtained from Video Electronics Standards Association (VESA). Extended Display Identification Data (EDID) information may be also obtained from VESA.

1. An i486 (or above) personal computer or compatible.
2. Microsoft operation system Windows 95/98/2000/XP.
3. "PORT95NT.exe, WinDDC_ setup" program
4. Software OSD SN Alignment kits

The kit contents:

- a. OSD SN BOARD x1
- b. Printer cable x1
- c. VGA cable x1
- d. Digital cable x1
- e. 12V DC power source

13.1. Install the "PORT95NT.EXE", and restart the computer.

The process of installing "PORT95NT" has been specified in, so it will not be specified again. If you have any problem, please read it.

13.2. Install the "WinDDC_setup"



13.3. Connect the DDC board as follow:




When you write analog EDID, Connect this port to the Philips 191EW9's VGA port


12V Input

Connect to the PC LPT



13.4. Take analog DDC write for example, as follow




a. Double-click **WinDDC.exe**, appear as follow Figs :



b. Click



c. Key 14 numbers in the Serial Number blank, then click "OK". Now analog DDC Write completes, as follow.



Note: The way of digital DDC write is the same as analog DDC write.

191EW9 EDID**Analog**

128 bytes EDID Data (Hex):

x0 x1 x2 x3 x4 x5 x6 x7 x8 x9 xA xB xC xD xE xF

```

0:  00 FF FF FF FF FF FF 00 41 0C 2A C0 63 3D 03 00
10: 1F 0D 01 03 6E 29 17 78 2A EE D1 A5 55 48 9B 26
20: 12 50 54 BF EF 80 71 4F 81 CF 01 01 01 01 01 01
30: 01 01 01 01 01 01 66 21 56 AA 51 00 1E 30 46 8F
40: 33 00 9D EA 10 00 00 1E 00 00 00 FF 00 31 33 32
50: 32 33 33 31 32 31 32 33 32 33 00 00 00 FD 00 38
60: 4C 1E 53 11 00 0A 20 20 20 20 20 20 00 00 00 FC
70: 00 50 68 69 6C 69 70 73 20 31 39 31 45 57 00 83

```

Decoded EDID data

<---Header--->

Header: 00 FF FF FF FF FF FF 00

<-x-Header-x->

<---Vendor/Product Identification--->

```

ID Manufacturer Name:  PHL
ID Product Code:       C02A
ID Serial Number:      633d0300
Week of Manufacture:   31
Year of Manufacture:   2003

```

<-x-Vendor/Product Identification-x->

<---EDID Structure Version/Revision--->

```

EDID Version#:         01
EDID Revision#:        03

```

<-x-EDID Structure Version/Revision-x->

<---Basic Display Parameters/Features--->

```

Video i/p definition:  Analog
Signal Level Standard: 0.700V/0.000V (0.700Vpp)
Setup:                 Blank-to-Black not expected
Separate Sync Support: Yes
Composite Sync Support: Yes
Sync. on green video supported: Yes
Serration of the Vsync. Pulse is not required.
Max. H. Image Size:    41cm.
Max. V. Image Size:    23cm.
Display Gamma:         2.2
DPMS Features, Stand-by: No.
DPMS Features, Suspend: No.
DPMS Features, Active off: Yes.
Display Type:          R.G.B color display.
Standard Default Color Space: R.G.B color.
Preferred Timing Mode: In First Detailed Timing
GTF supported: No.

```

<---Basic Display Parameters/Features--->

<---Color Characteristics--->

Red x: 0.6474609375
 Red y: 0.3339843750
 Green x: 0.2861328125
 Green y: 0.6074218750
 Blue x: 0.1513671875
 Blue y: 0.0712890625
 White x: 0.3125000000
 White y: 0.3291015625

<-x-Color Characteristics-x->

<---Established Timings--->

Established Timings 1: BF

-720x400 @70Hz VGA, IBM
 -640x480 @60Hz VGA, IBM
 -640x480 @67Hz Apple, Mac II
 -640x480 @72Hz VESA
 -640x480 @75Hz VESA
 -800x600 @56Hz VESA
 -800x600 @60Hz VESA

Established Timings 2: EF

-800x600 @72Hz VESA
 -800x600 @75Hz VESA
 -832x624 @75Hz Apple, Mac II
 -1024x768 @60Hz VESA
 -1024x768 @70Hz VESA
 -1024x768 @75Hz VESA
 -1280x1024 @75Hz VESA

Established Timings 3: 80

-1152x870 @75Hz Apple, Mac II

<-x-Established Timings-x->

<---Standard Timing Identification--->

-1152x864 @75 Hz
 -1280x720 @75 Hz

<-x-Standard Timing Identification-x->

<---Detailed Timing Descriptions--->

Detailed Timing: 1366x768 @ 60Hz

<-x-Detailed Timing Descriptions-x->

<---Detailed Timing Descriptions--->

Detailed Timing: FF (Monitor SN) '132233121232'

Detailed Timing: FD (Monitor limits)

Min. V. rate: 56Hz
 Max. V. rate: 76Hz
 Min. H. rate: 30 KHz
 Max. H. rate: 83 KHz
 Max. Pixel Clock: 170MHz

Detailed Timing: FC (Monitor Name) 'Philips 191EW'

<-x-Detailed Timing Descriptions-x->

Extension Flag: 00

Checksum: 83

Digital

128 bytes EDID Data (Hex):

x0 x1 x2 x3 x4 x5 x6 x7 x8 x9 xA xB xC xD xE xF

```

0:  00 FF FF FF FF FF FF 00 41 0C 2A C0 0B C4 04 00
10: 15 0C 01 03 80 29 17 78 2A EE D1 A5 55 48 9B 26
20: 12 50 54 BF EF 80 71 4F 81 CF 01 01 01 01 01 01
30: 01 01 01 01 01 01 66 21 56 AA 51 00 1E 30 46 8F
40: 33 00 9D EA 10 00 00 1E 00 00 00 FF 00 31 32 33
50: 31 32 32 31 33 31 32 33 33 31 00 00 00 FD 00 38
60: 4C 1E 53 11 00 0A 20 20 20 20 20 20 00 00 00 FC
70: 00 50 68 69 6C 69 70 73 20 31 39 31 45 57 00 4F

```

Decoded EDID data

<---Header--->

Header: 00 FF FF FF FF FF FF 00

<-x-Header-x->

<---Vendor/Product Identification--->

```

ID Manufacturer Name:  PHL
ID Product Code:       C02A
ID Serial Number:      0bc40400
Week of Manufacture:   21
Year of Manufacture:   2002

```

<-x-Vendor/Product Identification-x->

<---EDID Structure Version/Revision--->

```

EDID Version#:        01
EDID Revision#:       03

```

<-x-EDID Structure Version/Revision-x->

<---Basic Display Parameters/Features--->

```

Video i/p definition:  Digital
Max. H. Image Size:   41cm.
Max. V. Image Size:   23cm.
Display Gamma:        2.2
DPMS Features, Stand-by: No.
DPMS Features, Suspend: No.
DPMS Features, Active off: Yes.
Display Type:         R.G.B color display.
Standard Default Color Space: R.G.B color.
Preferred Timing Mode: In First Detailed Timing
GTF supported: No.

```

<---Basic Display Parameters/Features--->

<---Color Characteristics--->

```

Red x:      0.6474609375
Red y:      0.3339843750
Green x:    0.2861328125
Green y:    0.6074218750
Blue x:     0.1513671875
Blue y:     0.0712890625
White x:    0.3125000000
White y:    0.3291015625

```

<-x-Color Characteristics-x->

<---Established Timings--->

Established Timings 1: BF

- 720x400 @70Hz VGA, IBM
- 640x480 @60Hz VGA, IBM
- 640x480 @67Hz Apple, Mac II
- 640x480 @72Hz VESA
- 640x480 @75Hz VESA
- 800x600 @56Hz VESA
- 800x600 @60Hz VESA

Established Timings 2: EF

- 800x600 @72Hz VESA
- 800x600 @75Hz VESA
- 832x624 @75Hz Apple, Mac II
- 1024x768 @60Hz VESA
- 1024x768 @70Hz VESA
- 1024x768 @75Hz VESA
- 1280x1024 @75Hz VESA

Established Timings 3: 80

- 1152x870 @75Hz Apple, Mac II

<-x-Established Timings-x->

<---Standard Timing Identification--->

- 1152x864 @75 Hz
- 1280x720 @75 Hz

<-x-Standard Timing Identification-x->

<---Detailed Timing Descriptions--->

Detailed Timing: 1366x768 @ 60Hz

<-x-Detailed Timing Descriptions-x->

<---Detailed Timing Descriptions--->

Detailed Timing: FF (Monitor SN) '123122131233'

Detailed Timing: FD (Monitor limits)

- Min. V. rate: 56Hz
- Max. V. rate: 76Hz
- Min. H. rate: 30 KHz
- Max. H. rate: 83 KHz
- Max. Pixel Clock: 170MHz

Detailed Timing: FC (Monitor Name) 'Philips 191EW'


<-x-Detailed Timing Descriptions-x->

Extension Flag: 00

Checksum: 4F

14. White Balance, Luminance Adjustment

1. Apparatuses and program: analyzer CA-210, PC, tool, FGA adjustment program (PHILIPS 191EW9.DDCI), Pattern generator.
2. Equipment installation:
 - a. Connect analyzer CA-210 to PC by USB connector, install drive program CA-SDK Ver4.00 for CA-210 and restart PC after finish installing.
 - b. Install Port95NT drive program, set PC printer connector mode as ECP mode and restart PC after finish installing.
 - c. Connect tools as follow:
(Note: It is not necessary to connect Port2)




3. Adjustment

Preparation before adjustment:

- (1) Monitor should be warmed up for more than half an hour.
- (2) Make sure that the tools are connected right and drive programs have been installed OK.

Adjustment process:


- (1) Press the power of CA-210, shut off the lens, press 0-Cal and open the lens after analyzer reset.
- (2) Start white balance adjustment program; select the right parameter according with the program and click OK.
- (3) Make sure that the lens of CA-210 aims at the center of the screen, then click Start and start adjusting.
- (4) After finish adjusting, the adjustment program displays pass, and the Start Button is changed to Next, which means you can adjust another monitor.



4. Color Temp confirmation

Connect the signal to the monitor, the monitor display white-picture, use CA-210 to measure the Color Temp of the screen center and select the OSD to make sure whether the Color Temps accord with the SPEC.

15. Monitor Exploded View



16. Recommended & Spare Parts List

191EW9FB/00

| Item | Location | Philips 12NC | PCM Codes | Description | Remark |
|------|------------|--------------|--------------------|-------------------------------------|------------|
| 1 | FQ106 | 996510019630 | Q34G0488AFLA1B0130 | BEZEL(L185W-8qph1) | |
| 1 | FQ106 | 996510020289 | Q34G0488AFLC1B0130 | BEZEL(L185W-8qph1)(CMO) | 2nd source |
| 2 | FQ004 | 996510014830 | KEPC7QV9 | KEY BOARD ASSY | |
| 3 | FQ001 | 996510019373 | 750GLG185H1A12N000 | PANEL LM190WH1-TLA1 NJ LGD | |
| 3 | E750 | 996510020583 | 750GLM185B1312M0PH | PANEL M185B1-L03 NB CMO | 2nd source |
| 3 | E750 | 996510020583 | 750GLM185B1322M0PH | PANEL M185B1-L03 NB CMO | 2nd source |
| 4 | FQ003 | 996510019369 | PWPC8921LQCF | POWER BOARD ASSY | |
| 4 | FQ003 | 996510020580 | PWPC8921MQWE | POWER BOARD ASSY(CMO) | 2nd source |
| 5 | FQ002 | 996510019912 | 756GQ8CB PH001 | SCALER BOARD ASSY(CBPCRNFPHQ1) | LGD |
| 5 | FQ002 | 996510020581 | 756GQ8CB PH006 | SCALER BOARD ASSY(CBPCRNFPHQ3)(CMO) | 2nd source |
| 6 | FQ105 | 996510019364 | Q34G0415AFL 1B0100 | REAR COVER18.5" | |
| 7 | FQ103 | 996510019387 | 705GQ834344 | 18.5 LCD STAND BASE ASS'Y | |
| | SMTCR-U402 | 996510019926 | 100GPNG8002N11 | MCU ASS'Y-056G1133713 | |
| | SMTCR-U402 | 996510020582 | 100GPNM8000NT1 | MCU ASSY-056G1133713(CMO) | 2nd source |
| | E08902 | 996510014809 | 089G 725CAA DB | D-SUB CABLE | |
| | FQ304 | 996510015569 | 089G179J30N501 | FFC CABLE | LGD |
| | FQ304 | 996510020576 | 095G8018 3DH45 | LVDS CABLE 30P-24P 120mm(CMO) | 2nd source |
| | FQ301 | 996510015663 | 089G404A15N IS | POWER CORD | |
| | FQ405 | 996510019363 | Q33G0170AFL 1L0100 | KEY PAD | |
| | FQ205 | 996510019366 | 705GQ8CS051 | CUSHION ASSY | |
| | FQ202 | 996510019631 | Q44G8009813 2A | 18.5 PHILIPS LCD CARTON | |
| | FQ202 | 996510020579 | Q44G8009813 2B | 18.5 LCD PHILIPS CARTON(CMO) | 2nd source |

| | | | | | |
|--|-------|--------------|----------------|------------------------------|--|
| | IC902 | 996500036055 | 056G 139 3A | IC PC123Y22FZ0F | |
| | T801 | 996510006252 | 080GL17T 40 DN | X'FMR TK.2001U.101 | |
| | T901 | 996510007244 | 080GL19T 26 T | X'FMR 460uH SRW24LQL-T15H016 | |
| | IC801 | 996510006256 | 056G 379 22 | IC TL494IDR SOIC-16 | |
| | IC901 | 996510007250 | 056G 379 76 | IC LD7552BPS SOP-8 | |
| | IC903 | 996510002780 | 056G 158 10 T | IC AS431AZTR-E1 TO-92 | |
| | F901 | 996510017352 | 084G 56 3 B | FUSE 3.15A 250V | |
| | F903 | 996510017352 | 084G 56 3 B | FUSE 3.15A 250V | |
| | X401 | 996510019371 | 093G 2251B J | NXS12.000AC30F-BT-2 | |
| | U401 | 996510019372 | 056G 562573 | IC NT68167FG QFP64 | |
| | U404 | 996510005697 | 056G 563 52 | IC AP1117D33L-13 | |
| | U102 | 996510014826 | 056G 662 13 | IC AZC099-04S SOT23-6L | |
| | U103 | 996510014826 | 056G 662 13 | IC AZC099-04S SOT23-6L | |

Service Kit

| Description | Part No. | Philips 12NC | Remark |
|-----------------|------------|----------------|---|
| DDC KIT | 715L2005C2 | 9965 000 43197 | FOR ALL MODEL |
| OSD SN KIT | 715GT033 C | 9965 000 43252 | FOR ALL MODEL |
| NOVATEK ISP KIT | 715LT035A | 9965 000 43198 | FOR ALL HUDSON 7 |
| | | | FOR 170A8, 190B8, 150S8, 170S8, 190S8, 170V8, 190V8 |
| NOVATEK ISP KIT | 715GT048 1 | 996510018193 | FOR 190S9, 190B9, 190SW9, 190BW9, 191EW9 |
| MSTAR ISP KIT | 715GT039 A | 996510010027 | 200CW8, 190VW9, 170V9, 190V9 |
| REALTEK ISP KIT | 715GT039 A | 996510010027 | 170CW8 |

17. Different Parts List

| Diversity of 191EW9FB/75 compared with 191EW9FB/00 | | | | | | |
|--|--------------|--------------------|-------------------------------|--------------|--------------------|-------------------------------|
| 191EW9FB/75 | | | | 191EW9FB/00 | | |
| Location | Philips 12NC | PCM Codes | Description | Philips 12NC | PCM Codes | Description |
| FQ301 | 996510016841 | 089G412A15NIS3 | POWER CORD | 996510015663 | 089G404A15N IS | POWER CORD |
| FQ301 | 996500037345 | 089G412A18NIS3 | POWER CORD | 996510015663 | 089G404A15N IS | POWER CORD |
| FQ001 | 996510019925 | 750GLG185W1A12N000 | PANEL LM185WH1-TLA1 NJ LGD | 996510019373 | 750GLG185H1A12N000 | PANEL LM190WH1-TLA1 NJ LGD |

| Diversity of 191EW9FB/69 compared with 191EW9FB/00 | | | | | | |
|--|--------------|--------------------|-------------------------------|--------------|--------------------|-------------------------------|
| 191EW9FB/69 | | | | 191EW9FB/00 | | |
| Location | Philips 12NC | PCM Codes | Description | Philips 12NC | PCM Codes | Description |
| FQ301 | 996510019911 | 089G410A15N IS | POWER CORD WALL-OUT FOR UK | 996510015663 | 089G404A15N IS | POWER CORD |
| FQ001 | 996510019925 | 750GLG185W1A12N000 | PANEL LM185WH1-TLA1 NJ LGD | 996510019373 | 750GLG185H1A12N000 | PANEL LM190WH1-TLA1 NJ LGD |

| Diversity of 191EW9FB/97 compared with 191EW9FB/00 | | | | | | |
|--|--------------|--------------------|-------------------------------|--------------|--------------------|-------------------------------|
| 191EW9FB/97 | | | | 191EW9FB/00 | | |
| Location | Philips 12NC | PCM Codes | Description | Philips 12NC | PCM Codes | Description |
| FQ001 | 996510019925 | 750GLG185W1A12N000 | PANEL LM185WH1-TLA1 NJ LGD | 996510019373 | 750GLG185H1A12N000 | PANEL LM190WH1-TLA1 NJ LGD |

| Diversity of 191EW9FB/94 compared with 191EW9FB/00 | | | | | | |
|--|--------------|--------------------|-------------------------------|--------------|--------------------|-------------------------------|
| 191EW9FB/94 | | | | 191EW9FB/00 | | |
| Location | Philips 12NC | PCM Codes | Description | Philips 12NC | PCM Codes | Description |
| FQ301 | 996510015866 | 089G417A15N IS | POWER CORD | 996510015663 | 089G404A15N IS | POWER CORD |
| FQ001 | 996510019925 | 750GLG185W1A12N000 | PANEL LM185WH1-TLA1 NJ LGD | 996510019373 | 750GLG185H1A12N000 | PANEL LM185WH1-TLA1 NJ LGD |

| Diversity of 191EW9FB/93 compared with 191EW9FB/00 | | | | | | |
|--|--------------|--------------------|-------------------------------|--------------|--------------------|-------------------------------|
| 191EW9FB/93 | | | | 191EW9FB/00 | | |
| Location | Philips 12NC | PCM Codes | Description | Philips 12NC | PCM Codes | Description |
| FQ301 | 996510015859 | 089G414A15N IS | POWER CORD | 996510015663 | 089G404A15N IS | POWER CORD |
| FQ301 | 996510019982 | 089G414A15N LS | POWER CORD | 996510015663 | 089G404A15N IS | POWER CORD |
| FQ106 | 996510019365 | Q34G0488AFLB1B0130 | BEZEL(L185W-8QPH1) | 996510019630 | Q34G0488AFLA1B0130 | BEZEL(L185W-8QPH1) |
| FQ202 | 996510019388 | Q44G8009813 1A | 18.5 PHILIPS LCD CARTON | 996510019631 | Q44G8009813 2A | 18.5 PHILIPS LCD CARTON |
| FQ001 | 996510019925 | 750GLG185W1A12N000 | PANEL LM185WH1-TLA1 NJ LGD | 996510019373 | 750GLG185H1A12N000 | PANEL LM190WH1-TLA1 NJ LGD |
| FQ203 | 996510016085 | Q45G 88609 77 | EPE BAG FOR MONITOR | | | |
| FQ204 | 996510019368 | Q70G9002813 8A | 191EW9 CD MANUAL | | | |
| FQ206 | 996510019367 | Q41G780A81317A | 191EW9 QSG | | | |

| Diversity of 191EW9FB/05 compared with 191EW9FB/00 | | | | | | |
|--|--------------|--------------------|-------------------------------|--------------|--------------------|-------------------------------|
| 191EW9FB/05 | | | | 191EW9FB/00 | | |
| Location | Philips 12NC | PCM Codes | Description | Philips 12NC | PCM Codes | Description |
| FQ301 | | 089G410A15N IS | POWER CORD | | 089G404A15N IS | POWER CORD |
| FQ001 | | 750GLG185W1A12N000 | PANEL LM185WH1-TLA1 NJ LGD | | 750GLG185H1A12N000 | PANEL LM190WH1-TLA1 NJ LGD |

| Diversity of 191EW9FB/62 compared with 191EW9FB/00 | | | | | | |
|--|--------------|--------------------|-------------------------------|--------------|--------------------|-------------------------------|
| 191EW9FB/62 | | | | 191EW9FB/00 | | |
| Location | Philips 12NC | PCM Codes | Description | Philips 12NC | PCM Codes | Description |
| FQ001 | | 750GLG185W1A12N000 | PANEL LM185WH1-TLA1 NJ LGD | | 750GLG185H1A12N000 | PANEL LM190WH1-TLA1 NJ LGD |
| FQ106 | | Q34G0488AFLC1B0130 | BEZEL(L185W-8qph1) | | Q34G0488AFLA1B0130 | BEZEL(L185W-8QPH1) |

18. General Product Specification

CONTENTS

- 1 FOREWORD
- 2 PRODUCT PROFILE
 - 2.1 LCD
 - 2.2 SCANNING FREQUENCIES
 - 2.3 AMBIENT TEMPERATURE: 0 °C - 40 °C
- 3 ELECTRICAL CHARACTERISTICS
 - 3.1 INTERFACE SIGNALS
 - 3.2 INTERFACE
 - 3.3 TIMING REQUIREMENT
 - 3.4 HORIZONTAL SCANNING
 - 3.5 VERTICAL SCANNING
 - 3.6 POWER INPUT CONNECTION
 - 3.7 POWER MANAGEMENT (SUPPLIER TO INPUT)
 - 3.8 VGA DISPLAY IDENTIFICATION
 - 3.9 DDC/CI SUPPORT
 - 3.10 DATA FOR EDID & INF FILE
 - 3.11 HOT-KEY DEFINITION
- 4 VISUAL CHARACTERISTICS
 - 4.1 TEST CONDITIONS
 - 4.2 BRIGHTNESS
 - 4.3 IMAGE SIZE
 - 4.4 BRIGHTNESS UNIFORMITY
 - 4.5 CHECK CROSS TALK (S)
 - 4.6 WHITE COLOR ADJUSTMENT
- 5 MECHANICAL CHARACTERISTICS
 - 5.1 COSMETIC PHILIPS ID
 - 5.2 MECHANICAL DATA FILES PROE FILES REQUIRED
 - 5.3 LOCATION OF PHILIPS LOGO PER PHILIPS MAKE-UP SHEET
 - 5.4 GAP BETWEEN PANEL AND FRONT BEZEL <1.0MM
 - 5.5 LOCATION OF CONTROL ICONS- PER PHILIPS GRAPHIC SHEET
 - 5.6 COLOR FOR RESIN/PAINT PER PHILIPS MAKE-UP SHEET
 - 5.7 RESINS
 - 5.8 IF RAIN IS USED
 - 5.9 PLASTIC MOLD TOOLING
 - 5.10 PLASTICS FLAMMABILITY
 - 5.11 TEXTURE/GLOSSING OF HOUSING
 - 5.12 TILT AND SWIVEL BASE
 - 5.13 KENNSINGTON LOCK
 - 5.14 LABEL
 - 5.15 PRODUCT DIMENSION/WEIGHT/ WEIGHT (REFER TO SHT 191)
 - 5.16 TRANSPORTATION

5.17 PALLET / CONTAINER LOADING (REFER TO PHILIPS APPROVED SHT 560)

6. ENVIRONMENTAL CHARACTERISTICS

6.1 SUSCEPTIBILITY OF DISPLAY TO EXTERNAL ENVIRONMENT

6.2 TRANSPORTATION TESTS

6.3 DISPLAY DISTURBANCES FROM EXTERNAL ENVIRONMENT

6.4 DISPLAY DISTURBANCES TO EXTERNAL ENVIRONMENT

7. RELIABILITY

7.1 MEAN TIME BETWEEN FAILURES

8. QUALITY ASSURANCE REQUIREMENTS

8.1 ACCEPTANCE TEST

9. PHILIPS' FLAT PANEL MONITORS PIXEL DEFECT POLICY

10. REGULATORY COMPLIANCE

10.1 WORLDWIDE REGULATORY

10.2 EMC REQUIREMENTS

10.3 ROHS

10.4 WEEE

10.5 ONGOING REGULATORY

1. FOREWORD

This specification describes a 19" WXGA multi-scan color TFT LCD monitor with maximum resolution up to 1366*768 /75 Hz non-interlaced.

All optical characteristics (including WHITE-D, Brightness, and so on) are determined according to panel specification after warming up approximate 30 minutes that brightness stability is optimal, and follow strictly after panel specification.

2. PRODUCT PROFILE

This display monitor unit is a color display monitor enclosed in PHILIPS styling cabinet which has an integrated tilt base.

2.1 LCD

Tier 1: LGD

2.1.1

| | |
|-------------------------|--|
| Type NR. | : LM190WH1-TLA1 (TN) |
| Outside dimensions | : 430.4(H) x 254.6(V) x 13.0(D) mm (Typ) |
| Pitch (mm) | : 0.10*RGB (H) mm x 0.30(V) mm |
| Color pixel arrangement | : RGB vertical stripes |
| Display surface | : Hard coating (3H), Anti-glare treatment of the front polarizer |
| Color depth | : 16.7 M colors |
| Backlight | : CCFL edge light system |
| Active area (W x H) | : 409.8 (H) x 230.4 (V) |
| View angle | : Horizontal 170 (Typ.), Vertical 160 (Typ.) |
| Contrast ratio | : 1000:1 (typical) |
| White luminance | : 300 nits (Typ.) |
| Gate IC | : |
| Source IC | : |
| Response time | : 5ms (Typ) |
| MTBF | : 50,000Hrs |

2.2 Scanning frequencies

| | |
|-------------------|---------------------------------|
| Hor. | : 30 – 83 K Hz |
| Ver. | : 56 - 76 Hz |
| Video dot rate | : <140 MHz |
| Power input | : 90-264 V AC, 50/60 \pm 2 Hz |
| Power consumption | : < 40W maximum, < 36W (Typ.) |

Functions:

(1) D-SUB analog R/G/B separate inputs, H/V sync separated, Composite (H+V) TTL level, SOG sync

2.3 Ambient temperature: 0 °C - 40°C

3. Electrical characteristics

3.1 Interface signals

1). D-Sub Analog

Input signal: Video, Hsync, Vsync

Video: 0.7 Vp-p, input impedance, 75 ohm @DC

Sync. Separate sync TTL level, input impedance 2.2k ohm terminate

Hsync Positive/Negative

Vsync Positive/Negative

Composite sync TTL level, input impedance 2.2k ohm terminate (Positive/Negative)

Sync on green video 0.3 Vp-p Negative (Video 0.7 Vp-p Positive)

3.2 Interface

3.2.1 D-Sub Cable

Length : 1.5 M +/- 50 mm

Fix with monitor when packing, with transplant pin protective cover.

Connector type : D-Sub male with DDC2B pin assignments.
Blue connector thumb-operated jack screws

Pin assignments:

| Pin No. | Description |
|---------|---------------------|
| 1 | Red |
| 2 | Green/ SOG |
| 3 | Blue |
| 4 | Sense (GND) |
| 5 | Cable Detect (GND) |
| 6 | Red GND |
| 7 | Green GND |
| 8 | Blue GND |
| 9 | DDC +3.3V or +5V |
| 10 | Logic GND |
| 11 | Sense (GND) |
| 12 | Bi-directional data |
| 13 | H/H+V sync |
| 14 | V-sync |
| 15 | Data clock |

3.2.2 Software control functions via OSD /control adjustable functions:

Please refer to following Hudson8 OSD definitions

Reset - No: Exit

Yes: Auto adjustment for displaying timing mode and recall factory preset

OSD Tree

| Level 1 | Level 2 | Level 3 | Default |
|-------------|-------------------------|---------------------|-------------|
| Picture | Picture Format | Wide Screen, 4:3 | Wide Screen |
| | Brightness | (0~100) | 100 |
| | Contrast | (0~100) | 50 |
| | Smart Contrast | On, Off | Off |
| Color | Color Temp. | (6500K,9300K) | 6500K |
| | sRGB | | |
| | User Define | (Red:0~100) | 100 |
| | | (Green:0~100) | 100 |
| | | (Blue:0~100) | 100 |
| Language | English | | (English) |
| | Espanol | | |
| | Francais | | |
| | Deutsch | | |
| | Italiano | | |
| | Portugues | | |
| | Russia | | |
| | S.Chinese | | |
| OSD Setting | Horizontal | (0~100) | 50 |
| | Vertical | (0~100) | 50 |
| | Transparency | (Off, 1, 2, 3, 4) | Off |
| | OSD Time out | (5, 10, 20, 30, 60) | 20 |
| Setup | Phase | (0~100) | |
| | Clock | (0~100) | |
| | H.Position | (0~100) | |
| | V.Position | (0~100) | |
| | Reset | (Yes, No) | No |
| | Resolution Notification | (On, Off) | Off |
| | Information | | |

3.3 Timing requirement

Factory Preset mode definition:

1. Perfect FOS while presenting all required timings.
2. Required timings need to be specified in User's Manual.

User mode

1. Can be showed (not over scalar or Panel spec.)
2. It needs to reserve the 22 timings space in memory size.

3.3.1 Mode storing capacity

Factory preset modes : 10
User modes : 23

- Note:
1. Screen displays perfect picture at 10 factory-preset modes.
 2. Screen displays visible picture with OSD warning when input modes are the 22 preset modes.

3.3.2 Factory preset modes

Factory modes and preset modes are defined in the enclosed timing table file.

| Support Timing | Factory Preset Timing | Resolution | | | Pixel Rate (MHz) | Horizontal (KHz) | Vertical (Hz) |
|----------------|-----------------------|------------|------|-------------|--------------------|--------------------|-----------------|
| * | | DOS | | 640x350/70 | 25.18 | 31.47 | 70.09 |
| * | * | DOS | | 720x400/70 | 28.32 | 31.47 | 70.09 |
| * | * | DMT | 4:3 | 640x480/60 | 25.18 | 31.47 | 59.94 |
| * | | MAC | | 640x480/67 | 30.24 | 35.00 | 66.67 |
| * | | DMT | 4:3 | 640x480/72 | 31.50 | 37.86 | 72.81 |
| * | * | DMT | 4:3 | 640x480/75 | 31.50 | 37.50 | 75.00 |
| * | | DMT | 4:3 | 800x600/56 | 36.00 | 35.16 | 56.25 |
| * | * | DMT | 4:3 | 800x600/60 | 40.00 | 37.88 | 60.32 |
| * | | DMT | 4:3 | 800x600/72 | 50.00 | 48.08 | 72.19 |
| * | * | DMT | 4:3 | 800x600/75 | 49.50 | 46.88 | 75.00 |
| * | | MAC | | 832x624/75 | 57.28 | 47.73 | 74.55 |
| * | | WVGA | | 1024X600/60 | | | |
| * | * | DMT | 4:3 | 1024x768/60 | 65.00 | 48.36 | 60.00 |
| * | | DMT | 4:3 | 1024x768/70 | 75.00 | 56.48 | 70.07 |
| * | * | DMT | 4:3 | 1024x768/75 | 78.75 | 60.02 | 75.03 |
| * | | DMT | | 1152x864/75 | 108.00 | 67.50 | 75.00 |
| * | | MAC | | 1152x870/75 | 100.00 | 68.68 | 75.06 |
| * | | SUN | | 1152x900/66 | 92.94 | 61.80 | 65.95 |
| * | | SUN | | 1152x900/76 | 105.56 | 71.71 | 76.05 |
| * | | CVT | 16:9 | 1280x720/60 | 74.50 | 44.77 | 59.86 |
| * | | CVT | 16:9 | 1280x720/75 | 95.75 | 56.46 | 74.78 |
| * | | CVT | 15:9 | 1280x768/60 | 79.50 | 47.78 | 59.87 |
| * | | CVT | 15:9 | 1280x768/75 | 102.25 | 60.29 | 74.89 |
| * | | CVT | | 1280x800/60 | 83.50 | 49.70 | 59.81 |
| * | | CVT | | 1280x800/75 | 106.50 | 62.80 | 74.93 |
| * | | DMT | 4:3 | 1280x960/60 | 108.00 | 60.00 | 60.00 |

| | | | | | | | |
|---|---|-----|------|--------------|--------|-------|-------|
| * | * | DMT | 5:4 | 1280x1024/60 | 108.00 | 63.89 | 60.02 |
| * | | SUN | 5:4 | 1280x1024/66 | 117.00 | 71.70 | 67.00 |
| * | * | DMT | 5:4 | 1280x1024/75 | 135.00 | 79.98 | 75.03 |
| * | | SUN | 5:4 | 1280x1024/76 | 138.01 | 81.10 | 76.00 |
| * | | DMT | 16:9 | 1360x768/60 | 85.50 | 47.71 | 60.02 |
| * | | CVT | 16:9 | 1360x768/75 | 109.00 | 60.29 | 74.89 |
| * | * | CVT | 16:9 | 1366x768/60 | 85.50 | 47.71 | 59.79 |

3.4 Horizontal scanning

Sync polarity : Positive or Negative

Scanning frequency : 30 – 83 K Hz

3.5 Vertical scanning

Sync polarity : Positive or Negative

Scanning frequency : 56 - 76 Hz

3.6 Power input connection

Power cord length : 1.5 M (Waiting for suppliers input)

Power cord type : 3 leads power cord with protective earth plug.

3.7 Power management (supplier to input)

The monitor must comply with the Microsoft on Now specification, and meet EPA requirements.

| Mode | HSYNC | VSYNC | Video | Pwr-cons. | Indication | Rec. time |
|--------------|-------|-------|---------|---------------------------|------------|-----------|
| Power-On | On | On | active | < 40 W Max. <36 W Typ. | Green LED | -- |
| Power saving | Off | Off | blanked | < 0.8 W | Amber LED | < 3 s |
| DC Power Off | | | N/A | < 0.8 W | LED Off | |

* Energy star report less than 33 watt

3.8 VGA Display identification

In accordance with VESA Display Channel Standard Ver.1.0 and DDC 2B capability

3.9 DDC/CI Support

In accordance with VESA DDC/CI and MCCS ver.2.0, the monitor should be workable with Philips Smart Manage, Smart Control II V1.2, and Portrait Display Tune at least.

3.11 Data for EDID & .inf file

| | | |
|---|--------------------------------------|---|
| 1 | User visible strings on .inf file | Philips 191EW (19 inch Wide LCD MONITOR 191EW9) |
| 2 | Manufacture ID (EDID data) | PHL |
| 3 | Product ID, "xxxx" 4 codes | MSB (byte 12) :C0 |
| | | LSB (byte 11) : 2A |
| 4 | Maximum resolution | 1366X768 |
| 5 | Horizontal Frequency Range | 30~83 KHz |
| 6 | Vertical Frequency Range | 56~76 Hz |
| 7 | Monitor Name (13 characterizes max.) | Philips 191EW |

3.12 Hot-key definition

| Item | Key | Key Press Time | OSD Timeout | OSD Message |
|-------------------------|-----------------------|----------------|-------------|--|
| Monitor Controls Lock | [Menu] | 6 sec | 5 sec | Monitor controls locked Monitor controls unlocked (default) |
| Factory Mode | [AUTO]+[Menu]+[Power] | | | |
| DDC/CI On/OFF for VISTA | [MENU]+[DOWN] | 5 sec | 5 sec | DDC/CI ON (default) DDC/CI OFF |

4. Visual characteristics

4.1 Test conditions

Unless otherwise specified, this specification is defined under the following conditions.

- (1) Input signal: As defined in 3.3, 1366*768
non-interlaced mode (1366*768@60Hz 146.25MHz),
Signal sources must have 75 ohm output impedance..
- (2) Luminance setting : controls to be set to 300 nits with
Full screen 100 % duty cycle white signal
- (3) Warm up: more than 30 minutes after power on with signal supplied.
- (4) Ambient light: 400 -- 600 lux.
- (5) Ambient temperature: 20 ± 5 °C

4.2 Brightness

To follow Panel specification..

4.3 Image size

Actual display size: Refer to 2.1 LCD PANEL spec.

4.4 Brightness uniformity

Set contrast at 100% and turn the brightness to get average above 300 nits at centre of the screen.

Apply the Fig 1; it should comply with the following formula:

$$\frac{B_{\min}}{B_{\max}} \times 100\% > 75\% \text{ (Follow panel spec)}$$

Where B_Max. =Maximum brightness, B_Min. = Minimum brightness

4.5 Check Cross talk (S)

Apply Pattern 2. Set contrast and brightness at 100 %.

Measure YA. Then output Pattern 3 and measure YB.

The cross talk value:

$$\frac{ABS(YA - YB)}{YA} \times 100\% < 1.5\%$$

4.6 White color adjustment

There are three factory preset white color 9300K, 6500K, sRGB Align by FGA function.

Apply full gray64 pattern, with brightness in 100 % position and the contrast control at 50 % position.

The 1931 CIE Chromaticity (color triangle) diagram (x, y) coordinate for the screen center should be:

Product specification

| CIE coordinates | (x,y) | |
|-----------------|--|--|
| 9300K | x = 0.283 ± 0.015 y = 0.297 ± 0.015 | |
| 6500K/sRGB | x = 0.313 ± 0.015 y = 0.329 ± 0.015 | |
| sRGB | x = 0.313 ± 0.015 y = 0.329 ± 0.015 | |

5. Mechanical characteristics

5.1 Cosmetic -

Philips ID

5.2 Mechanical data files -

ProE files required

5.3 Location of Philips logo -

Per Philips make-up sheet

5.4 Gap between panel and front bezel

< 0.8 mm (typ)

5.5 Location of Control icons -

Per Philips Graphic sheet

5.6 Color for resin/paint -

Per Philips make-up sheet

5.7 Resins

- ROHS required
- WEEE required.
- Resin type/selection refers to Project Book Section 7.2 Plastic material.

5.8 If paint is used

- ROHS required
- WEEE require
- If new painting type needs to implement, refer to UN-D 1235.

5.9 Plastic mold tooling

- Tooling to be designed to minimize cosmetic defects induced by molding process (sink, blush, weld lines, gate marks, ejector marks, etc.). Refer to "TYV61-90007".
- Painting to cover up cosmetic defects due to molding is strongly discouraged.
- China ROHS mark requested.

5.10 Plastics flammability


- All Plastics to be Flame Retardant UL 94-HB.
- Base/Rear to be Flame Retardant UL 94-HB.
- All major plastic parts (bezel, back cover, base) need to be molded from same resin. Plastic resin type selection should be referred to "TY R83-2-9002-1".

5.11 Texture/Glossing of housing


- The texture area and texture no should follow Philips make-up sheet.
- The exterior surfaces shall have a uniform texture.
- Philips must approve the mold texturing.
- Detail document for texture refer to “UN-D249”, “UN-D 600”.

5.12 Tilt and swivel base

- Tilt angle : $-5^{\circ} +2/- 0^{\circ}$ (forward)
 $+20^{\circ} +0/- 2^{\circ}$ (backward)
- Tilt for left and right
 $|A-B| \leq 4.0\text{MM}$



- **Black side and cut side:**



1. Visual area

$$H: |L-R| \leq 1.5\text{mm}$$

$$V: |U-D| \leq 1.5\text{mm}$$

2. Black side on the left and right is symmetrical , not cut side.

- Gap between bezel and rear cover 0.4 mm (Typ.)
- Step between bezel and rear cover Left, right and top $\leq 0.6\text{mm}$ Bottom and corner $\leq 1.1\text{mm}$
- “Wobble”, “Twist”, etc. (front to back or side to side)

Whole monitor set shall retain stability within a short time after the applied external force disappears.
 20NT , 6secs (typ.) back to stable.

5.13 Kensington Lock

- Must meet Kensington_slot.spec “TYE-M0004”.

5.14 Label

- Carton label should follow Philips requirement.
- Regulatory label follow TPV OTS.
- China ROHS label
- Detail document refer to Philips Engineering Reference Book.

5.15 Product dimension / Weight (Refer to Philips approved SHT 191)

- Unit dimension : 439(w)*363(H)*191(D)
- Packed unit dimension : 490(w)*375(D)*145(H)
- Net weight : 3.98Kg
- Gross weight : 4.95Kg.

5.16 Transportation

Transportation standards follow TPV standard.

5.16.1 Transportation packages

Packaging and wrapping shall be sufficient to protect the product against damage or loss during shipment from the supplier to the destination specified in the purchase order. All packaging materials are subject to test and evaluation per TPV standard. The cushion material shall be constructed using EPS material.

5.16.2 Transportation Test

Follow TPV standard.

A. Transportation test specification for all regions

- Package test
 1. Random Vibration test
 2. Drop test

5.17 Pallet / Container loading

Transportation standards refer to follow TPV standard

- Air shipment -
- Sea container 20'(pallet/slip sheet)
- Sea container 40'(pallet/slip sheet)
- Sea container 40' High Cube (pallet/slip sheet)
- Land 53' MEGA Trailer (pallet/slip sheet)
- Land 53' MEGA Trailer per HQ (pallet/slip sheet)
- Truck shipment-

6. Environmental characteristics

The following sections define the interference and susceptibility condition limits that might occur between external environment and the display device.

6.1 Susceptibility of display to external environment

Operating

- Temperature : 0 to 40 degree C
- Humidity : 20%—90% max
- Altitude : 0-10000 ft
- Air pressure : 600-1100m BAR

Storage

- Temperature : -20 to 60 degree C
- Humidity : 10%-90% max
- Altitude : 0-30000 ft
- Air pressure : 300-1100m BAR

Note: recommend at 5 to 35°C, Humidity less than 60 %. Please also refer to DQE requirements.

6.2 Transportation tests

Refer to 5.15.2

6.3 Display disturbances from external environment

According to IEC 801-2 for ESD disturbances

6.4 Display disturbances to external environment

7. Reliability

7.1 Mean Time between Failures

System MTBF (Including the LCD panel and CCFL): Refer to 2.1 panel MTBF

8. Quality assurance requirements

8.1 Acceptance test

According to MIL-STD-105D Control II level

AQL: 0.4 (major)

1.5 (minor)

(Please also refer to annual quality agreement)

Customer acceptance criteria: UAW0377/00

9. Philips' Flat Panel Monitors Pixel Defect Policy

Philips' Flat Panel Monitors Pixel Defect Policy

| BRIGHT DOT DEFECTS | ACCEPTABLE LEVEL | | |
|---|--------------------|--|--|
| MODEL | 191EW9 | | |
| 1 lit sub-pixel | 3 | | |
| 2 adjacent lit sub-pixels | 1 | | |
| 3 adjacent lit sub-pixels (one white pixel) | 0 | | |
| Distance between two bright dot defects* | $\geq 25\text{mm}$ | | |
| Bright dot defects within 20 mm circle | 0 | | |
| Total bright dot defects of all type | 3 | | |

| BLACK DOT DEFECTS | ACCEPTABLE LEVEL | | |
|--|--------------------|--|--|
| MODEL | 191EW9 | | |
| 1 dark sub-pixel | 5 | | |
| 2 adjacent dark sub-pixels | 2 | | |
| 3 adjacent dark sub-pixels (one white pixel) | 0 | | |
| Distance between two black dot defects* | $\geq 15\text{mm}$ | | |
| Black dot defects within 20 mm circle* | 1 | | |
| Total black dot defects of all type | 5 | | |

| TOTAL DOT DEFECTS | ACCEPTABLE LEVEL | | |
|---|------------------|--|--|
| MODEL | 191EW9 | | |
| Total bright or black dot defects of all type | 5 | | |

* 1 or 2 adjacent sub-pixel defects = 1 dot defect

Fig 1: Measurement locations of Brightness Uniformity




Fig 2: Cross talk pattern

Gray level 46 (64 Gray level)














Fig 3: Cross talk Pattern









Center at Gray level 0 (Black)














10. REGULATORY COMPLIANCE

10.1 Worldwide Regulatory

| REGION (RSO) | COUNTRY (NSO) | DOMAIN | SAFETY / EMC / ERGONOMICS / STANDARDS | DOCUMENTS | REFERENCE LOGO |
|--------------|---------------|--------|--|--|---|
| World wide | World wide | Sa | IEC60950-1:2001. Group and national differences of all countries listed in CB Bulletin No. 107A | CB Report, certificate | |
| Europe | EUROPE | Sa | European Low Voltage Directives 73/23/EEC and 93/68/EEC, 2004/108/EC | Declaration of Conformity and Identity declaration |  |
| | | E | European Electromagnetic Compatibility Directive 2004/108/EC EN55022:2006, EN55024:1998+A1:2001+A2:2003, EN61000-3-2:2006, EN61000-3-3:1995+A1:2001+A2:2005 | EMC/CE test report | |
| | GERMANY | Sa | EN60950-1:2001 | TUV certificate |  |
| | | O | LCD: ISO13406-2, prEN 50279:1998 | TUV-ERG certificate and TUV ISO13406-2 report |  |
| | | O | GS-Mark / EK1-ITB 2000 | TUV-GS certificate |  |
| | | O | ISO13406-2 | TUV ISO13406-2 certificate |  |
| | | O | TUV MPR-II | TUV MPR-II certificate |  |
| | SWEDEN | Sa | EN60950-1:2001 | SEMKO certificate |  |
| | | O | TCO'99 | TCO report and certificate |  |
| | | O | TCO'03, or TCO'0x supersedes new standard | TCO report and certificate |  |

| | | | | | |
|----|----------------|----|---|----------------------------|---|
| | | O | TCO'06 | TCO report and certificate |  |
| | Switzerland | Sa | EN60950-1:2001 | S+ PZ1 certificate |  |
| | | E | EN55020,EN55024, IEC61000-3-2 ,IEC61000-3-3 | S+ PZ1 certificate | |
| | | O | EMF EN 50392 | EN 50392 report | |
| | Eastern Europe | Sa | EN60950-1:2001 | Certificate of Conformity | |
| | | E | EN55022,EN55024, IEC61000-3-2 ,IEC61000-3-3 | Certificate of Conformity | |
| | RUSSIA | Sa | GOST R 50377-1992 | GOST certificate |  |
| | ISRAEL | Sa | IS 1121, IEC60950/IEC60950-1 | Certificate of Conformity | |
| | ISRAEL | E | CISPR22 | Certificate of Conformity | |
| AP | KOREA | Sa | Korean Safety Control law IEC 60950 | eK certificate |  |
| | | E | Regulations laws: EMI 1996-78, 80. EMS 1996-79,81 | MIC certificate |  |
| | SINGAPORE | Sa | IEC60950 | PSB certificate |  |
| | CHINA | Sa | GB4943-2001 | CCC certificate |  |
| | | E | GB9254-1998; 17625.1-2003 | CCC certificate | |
| | | O | CSC/G1205-2004 | CECP certificate |  |

| | | | | | |
|-------|---------------------------|----|--|-------------------------|---|
| | TAIWAN | Sa | CNS-14336 (IEC 60950-1) | BSMI certificate |  R33048 |
| | | E | CNS-13438 (CISPR22) Class B | BSMI certificate | |
| | | O | Criteria 18 (Monitor) (LCD) | GreenMark / certificate | |
| | AUSTRALIA/ NEW-ZEALAND | E | AS/NZS3548:1995 AS/NZS CISPR22: 2002 Class B | CB, EMC report |  |
| | Saudi Arabia | Sa | EN60950-1:2001 | SASO | |
| | Saudi Arabia | Sa | EN55022, EN61000-3-2, EN61000-3-3, EN55024 | SASO | |
| | Japan | E | VCCI class B (CISPR 22) | VCCI Certificate |  |
| | Cambodia | Sa | EN60950-1:2001 | ISC certificate |  012106 |
| | Kuwait | Sa | EN60950-1:2001, 'Kuwait Conformity Assurance Scheme' (KUCAS) | KUCAS registration | |
| NAFTA | USA | Sa | UL 60950-1: 2003 | UL certificate, cUL |  UL60950 64E9 E118405 |
| | | E | FCC Part 15 Class B | FCC report and DoC |  |
| | | O | Energy Star | EPA test data |  |
| | CANADA | Sa | CSA C22.2 No 60950 | CSA certificate or cUL |  LR58447 |
| | | E | ICES-003 issue 3 | Statement on label | |
| | | | | | |

| | | | | | |
|--------------|--------------|----|--------------------------------|----------------------------|---|
| | MEXICO | Sa | NOM-019-SCFI-1994 | NOM certificate |  |
| LATAM | Argentina | Sa | EN60950-1:2001 | TUV S-mark or IRAM |  |
| | Brazil | Sa | UL 60950-1: 2003 | UL certificate or cUL | |
| | | E | FCC Part 15 Class B | FCC report and DoC | |
| | | O | Energy Star | EPA test data | |
| | | O | TCO'99 | TCO report and certificate | |
| | | O | TCO'03 | TCO report and certificate | |
| | | O | TCO'06 | TCO report and certificate | |
| South Africa | SOUTH AFRICA | Sa | SABS IEC 60950 and IEC 60950-1 | Certificate of Conformity |  |
| | | E | EN55022 or Crisper 22 | Certificate of Conformity | |

Sa = Safety

E = Electromagnetic Compatibility

O = Other which including recycling, energy saving, ergonomics

X=X-Ray

10.2 EMC Requirements

Supplier DVT EMI test result must be submitted prior to DVT samples delivery, and PVT EMI test result must be submitted again prior to PVT samples delivery, which also has to meet Philips' immunity testing specification.

10.3 ROHS

Restriction on the use of certain hazardous substances.

Lead, Cadmium, Mercury, Hexavalent Chromium, Polybrominated Biphenyl (PBB) and Polybrominated Biphenyl Ether (PBDE) (flame retardant).

10.4 WEEE

Producer (Philips) responsible for retailer take back schemes and recycling.

--System implemented.

--Collection and recycle targets.

10.5 Ongoing Regulatory

There's a possibility that other regulatory certificates will be required during the life of the product. It is the responsibility of the supplier to provide related documentation.

TELEVISION/MONITOR SAFETY GUIDELINES FOR THE PROFESSIONAL SERVICE TECHNICIAN

Safety Checks

After the original service problem has been corrected, a complete safety check should be made. Be sure to check over the entire set, not just the areas where you have worked. Some previous service may have left an unsafe condition, which could be unknowingly passed on to your customer. Be sure to check all of the following:

Fire and Shock Hazard

1. Be sure all components are positioned in such a way as to avoid the possibility of adjacent component shorts. This is especially important on those chassis which are transported to and from the service shop.
2. Never release a repaired unit unless all protective devices such as insulators, barriers, covers, strain reliefs, and other hardware have been installed in accordance with the original design.
3. Soldering and wiring must be inspected to locate possible cold solder joints, solder splashes, sharp solder points, frayed leads, pinched leads, or damaged insulation (including the ac cord). Be certain to remove loose solder balls and all other loose foreign particles.
4. Check across-the-line components and other components for physical evidence of damage or deterioration and replace if necessary. Follow original layout, lead length, and dress.
5. No lead or component should touch a receiving tube or a resistor rated at 1 watt or more. Lead tension around protruding metal surfaces or edges must be avoided.
6. Critical components having special safety characteristics are identified with an asterisk by the Ref. No. in the parts list and enclosed within a broken line * (where several critical components are grouped in one area) along with the safety symbols on the schematic diagrams and/or exploded views.
7. When servicing any unit, always use a separate isolation transformer for the chassis. Failure to use a separate isolation transformer may expose you to possible shock hazard, and may cause damage to servicing instruments.
8. Many electronic products use a polarized ac line cord (one wide pin on the plug.) Defeating this safety feature may create a potential hazard to the service and the user. Extension cords which do not incorporate the polarizing feature should never be used.
9. After reassembly of the unit, always perform a leakage test or resistance test from the line cord to all exposed metal parts of the cabinet. Also check all metal control shafts (with knobs removed), antenna terminals, handles, screws, etc. to be sure the unit may be safely operated without danger of electrical shock.

* Broken line

Implosion

1. All picture tubes used in current model receivers are equipped with an integral implosion system. Care should always be used, and safety glasses worn, whenever handling any picture tube. Avoid scratching or otherwise damaging the picture tube during installation.
2. Use only replacement tubes specified by the manufacturer.


X-radiation

1. Be sure procedures and instructions to all your service personnel cover the subject of X-radiation. Potential sources of X-rays in TV receivers are the picture tube and the high voltage circuits. The basic precaution which must be exercised is to keep the high voltage at the factory recommended level.
2. To avoid possible exposure to X-radiation and electrical shock, only the manufacturer's specified anode connectors must be used.
3. It is essential that the service technician has an accurate HV meter available at all times. The calibration of this meter should be checked periodically against a reference standard.
4. When the HV circuitry is operating properly there is no possibility of an X-radiation problem. High voltage should always be kept at the manufacturer's rated value—no higher—for optimum performance. Every time a color set is serviced, the brightness should be run up and down while monitoring the HV with a meter to be certain that the HV is regulated correctly and does not exceed the specified value. We suggest that you and your technicians review test procedures so that HV and HV regulation are always checked as a standard servicing procedure, and the reason for this prudent routine is clearly understood by everyone. It is important to use an accurate and reliable HV meter. It is recommended that the HV recorded on each customer's invoice, which will demonstrate a proper concern for the customer's safety.
5. When troubleshooting and making test measurements in a receiver with a problem of excessive high voltage, reduce the line voltage by means of a Variac to bring the HV into acceptable limits while troubleshooting. Do not operate the chassis longer than necessary to locate the cause of the excessive HV.

6. New picture tubes are specifically designed to withstand higher operating voltages without creating undesirable X-radiation. It is strongly recommended that any shop test fixture which is to be used with the new higher voltage chassis be equipped with one of the new type tubes designed for this service. Addition of a permanently connected HV meter to the shop test fixture is advisable. The CRT types used in these new sets should never be replaced with any other types, as this may result in excessive X-radiation.
7. It is essential to use the specified picture tube to avoid a possible X-radiation problem.
8. Most TV receivers contain some type of emergency "Hold Down" circuit to prevent HV from rising to excessive levels in the presence of a failure mode. These various circuits should be understood by all technicians servicing them, especially since many hold down circuits are inoperative as long as the receiver performs normally.

Leakage Current Cold Check

1. Unplug the ac line cord and connect a jumper between the two prongs of the plug.
2. Turn on the power switch.
3. Measure the resistance value between the jumpered ac plug and all exposed cabinet parts of the receiver, such as screw heads, antennas, and control shafts. When the exposed metallic part has a return path to the chassis, the reading should be between 1 megohm and 5.2 megohms. When the exposed metal does not have a return path to the chassis, the reading must be infinity. Remove the jumper from the ac line cord.

**Leakage Current Hot Check**

1. Do not use an isolation transformer for this test. Plug the completely reassembled receiver directly into the ac outlet.
2. Connect a 1.5k, 10w resistor paralleled by a 0.15uf. capacitor between each exposed metallic cabinet part and a good earth ground such as a water pipe, as shown above.
3. Use an ac voltmeter with at least 5000 ohms volt sensitivity to measure the potential across the resistor.
4. The potential at any point should not exceed 0.75 volts. A leakage current tester may be used to make this test; leakage current must not exceed 0.5 milliamps. If a measurement is outside of the specified limits, there is a possibility of shock hazard. The receiver should be repaired and rechecked before returning it to the customer.
5. Repeat the above procedure with the ac plug reversed. (Note: An ac adapter is necessary when a polarized plug is used. Do not defeat the polarizing feature of the plug.)

Picture Tube Replacement

The primary source of X-radiation in this television receiver is the picture tube. The picture tube utilized in this chassis is specially constructed to limit X-radiation emissions. For continued X-radiation protection, the replacement tube must be the same type as the original, including suffix letter, or a Philips approved type.

Parts Replacement

Many electrical and mechanical parts in Philips television sets have special safety related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. The use of a substitute part which does not have the same safety characteristics as the Philips recommended replacement part shown in this service manual may create shock, fire, or other hazards.

WARNING: Before removing the CRT anode cap, turn the unit **OFF** and short the HIGH VOLTAGE to the CRT DAG ground.
SERVICE NOTE: The CRT DAG is not at chassis ground.